



GB

For shower columns without mixer: 1, 6a, 7a or 7b (check the system that your product is equipped with), 8a

For shower columns with mixer: 1, 2, 3, 4, 5a (with thermostatic mixer) or 5b (with single lever mixer), 6b or 6c (check the system that your product is equipped with), 7a or 7b (check the system that your product is equipped with), 8b

RO

Pentru coloanele de dus fara baterie: 1, 6a, 7a sau 7b (in functie de sistemul cu care este echipat produsul), 8a

Pentru coloanele de dus cu baterie inclusa: 1, 2, 3, 4, 5a (cu baterie termostata) sau 5b (cu baterie monocomanda), 6b sau 6c (in functie de sistemul cu care este echipat produsul), 7a sau 7b (in functie de sistemul cu care este echipat produsul), 8b

RUS

Душевая колонна, хромированная: 1, 6a, 7a или 7b (проверьте систему, которую имеет ваш продукт), 8a

Душевая колонна, с смесителем: 1, 2, 3, 4, 5a (с смеситель термостатический) или 5b (с однорычажным смесителем), 6b or 6c (проверьте систему, которую имеет ваш продукт), 7a или 7b (проверьте систему, которую имеет ваш продукт), 8b

GB

Do not use abrasive sponges, scouring agents, organic solvents or acidic cleaners, limescale removers, household vinegar or cleaners containing acetic acid for cleaning.

RO

Nu utilizați pentru curățare bureți duri, substanțe abrazive, substanțe de curățare care conțin solvenți sau acizi, produse anti-tartru, oțet de bucătărie și substanțe de curățare pe bază de acid acetic.

RUS

При очистке не применяйте абразивные чистящие средства, оставляющие царапины губки, чистящие средства с содержанием кислот или растворителей, средства для удаления извести, пищевой уксус и чистящие средства с содержанием уксусной кислоты.