

ASSEMBLY INSTRUCTIONS

Shower Tray



1 Install the trap on to the waste hole of shower tray.



2 Fullfill the area for installation with dry sand and make it flat smoothly.



3 Place the shower tray temporarily to assembly position. The take it out, watch the traces on the sand. Add some sand if necessary for filling purposes.



4 Place the shower in its location and fix the trap to waste water piping. Always check the balance with the help of a water gauge.



5 Do not give any additional slope since the shower trays have already a slope within. Protect the item until the end of construction work.