

General installation instructions

When installing pay attention on the arrow punched on the body. The arrow marks the water flow direction.

INSTALLATION

Before installing mixers, faucets or any other component, pay attention to be sure that water pipes are free of rubbles and clean, in order to avoid functionality problems and to guarantee the product lifetime.

Don't connect the electric grounding to the flexibles or any other water pipe in the hydraulic system.

Turn off the water supply in case of long absence.

Faucets and mixers use parameters

Working pressure 1-5 bar.

For higher pressures we recommend the installation of a pressure reducer.

Max inlet hot water temperature 80 °C.

Warning! Don't force the faucet thread in the wall connectors, the thread can crack during the installation and it can cause leaks straight away or in a later time.

CLEANING

In order to keep the mixers/faucets good aesthetic for long time, just respect and observe some simple indication:

- Clean the limestone stains with water and soap or specific products for chrome plated surfaces.
- Do not use acid or granular detergent as well as abrasive or metal sponge.
- Plastic components must not be cleaned with alcohol-base detergents for any other solvent.

WARRANTY

The warranty is not effective on following situations:

- Wrong use.
- Wrong installation or installation made with wrong tools.
- Wrong maintenance or lack of maintenance.
- Wrong cleaning products or wrong cleaning products use.
- On components subject to normal usury.
- For limestone damages or pipes obstruction.
- Use of not genuine spare parts.
- For chemical, electric or electrochemical damages.