




INSTALLATION INSTRUCTIONS




1. Five spare part: A, B, C, D, E, F (as shown).




2. As shown, installing B into the screw rod & keeping screw notch vertically upward.




3. Inserting C into the mounting hole & keeping the threaded hole vertically upward.



4. Inserting B into C & fixing D slightly above C.



5. Installing D into the screw hole of C & Fixing it on the mounting hole by using A.



6. Installation completed, please be seated to check the stability.

Cleaning and maintenance

1. The products should not be cleaned with any acidic or abrasive cleansers.
2. The products' surfaces should be cleaned with a soft cloth and a solution of a gentle cleanser.

