

## Installation of wash basin

### First: Installation environment



1. Please turn off the water before install wash basin, and should have been aside of sewage and water supply pipes.
2. If you replace the old wash basin, turn off the water before you dismantling it.

### Second: Installation steps


1. Please put down wash basin on the table, and should have been aside under the table of tap of water supply pipe, drainage and inlet angle valve. Using a pen to describe basin shape on the table.

#### Notice:


- ① Please consider size of tap when you install wash basin. If too close the wall, maybe the drainer can not install or can not use as normal.
- ② Advice the distance is 820mm from table surface to the floor.
2. Then using a pen to describe a small basin inside contour line, Cutting out a less than 10-15 mm contour line surrounding the installation hole.



3. Installing tap and drainer on wash basin according to the installation requirement and steps




4. Put wash basin on the install hole of table, make sure the position, checking interval and make a mark:



5. ① After checking, put down wash basin on the table, coated with seal materail such as silica gel on outer edge of wash basin.

- ② Put wash basin on the table install hole carefully, And to align with the previous mark, then press basin tightly.

**Notice:** Do not using of epoxy resin adhesive.



6. After sealing material getting harden, connecting the inlet pipe and outlet pipe.

