

Instruction

● DESCRIPTION:

This hand dryer is electronic sensor operated, stainless steel cover, aluminum fixed board and double temperature protection device makes the machine strong, safe and reliable.

When put your hands under the air outlet, the machine starts work automatically to blow comfortable warm wind and dry your hands fast. When move your hands away from the air outlet, the machine stops work automatically.

● TECHNICAL DATA:

Rated voltage: 230V~ 50Hz

Rated power: 2300W

Detective distance: 50~200mm

● INSTALLATION:

Ready for installation:

Please choose a consolidated and vertical wall to install this product, make sure the area within a radius of 150mm of the product must be a vertical wall surface.

Please avoid to install this product in a place where the machine become obstructive or the machine is possibly hit by a open door.

Installation:

1. Drill 4 holes on the wall and insert the plastic dowels into the holes as figure 4.
2. Screw out the two screw from cover with the hexagon wrench enclosed with the machine as figure 1, discharge the cover as figure 2 and disconnect the sensor wire connector from circuit board as figure 3. (Pay attention: Discharge the cover carefully to avoid break the sensor wire.)


3. Screw the fixed board onto the wall with the screw enclosed with the machine as figure 5, then connect sensor wire connector to circuit board and screw the cover to the fixed board with 2 hexagon screws as figure 6. (Insure the sensor wire is never crushed by the cover when install.)

● OPERATION:

1. Insert the plug into the socket (230V~ 50Hz).
2. Put yours hands under the air outlet within 200mm under the sensor to get comfortable warm wind. The machine stops work when your hands leave the detective region for 3 seconds, and it stops work automatically as well after working continuously exceeding the programmed time 1 minute as self-protect, re-detection makes it work again.

● CAUTION


1. Installation of this product should be done by a qualified technician
2. The product should be installed onto consolidated wall
3. Do not use this product in any hot or moist place.
4. Cleaning the machine with water is prohibited, it may rise electric shock or catch a fire.
5. When the product is not in use for a long time, please cut off the power.

6.  Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities. Contact your local government for information regarding the collection systems available.

If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well-being.

When replacing old appliances with new ones, the retailer is legally obligated to take back your old appliance for disposals at least free of charge .

7. Should any damaged happened to the power cord, please call the qualified technicians for repairing or return to the manufacture for repair .

8.  Keep this product out of heat, humidity environments, such as shower room or other wet area.

HAND DRYER INSTRUCTIONS

