

VISION		v230914		Product fiche and information - Water heaters																				
I Load profile		IV Annual electricity consumption [kWh/annum]								VII Storage volume [l]						Sound power level								
II Water heating energy efficiency class		V Thermostat temperature setting [°C]								VIII Mixed water at 40°C [l]						15 [dB]								
III Water heating energy efficiency [%]		VI Daily electricity consumption [kWh]								IX Water heating energy efficiency [%]														
		Regulation EU 812/2013				Regulation EU 814/2013						Regulation EU 812/2013				Regulation EU 814/2013								
Model	I	II	III	IV	V	VI	VII	VIII	IX	Model	I	II	III	IV	V	VI	VII	VIII	IX					
HABITAT EWH 30	S	C	35	531	60	2,515	-	-	34,7	HABITAT EWH 80	M	C	36	1412	60	6,602	-	120	36,4					
HABITAT EWH 50	M	C	37	1392	60	6,484	-	70	36,9	HABITAT EWH 100	M	C	37	1383	60	6,433	-	144	37,1					
During product installation, use, service, and maintenance it is compulsory to comply strictly with all instructions in the user guide for installation and usage, as well as with product warranty card.																								
Once the product lifetime is terminated it must be dumped in accordance with the provision of legislation in force (regulations and directives) concerning its correct disassembly, disposal, and recycling, as well protection of mankind and the environment.																								
VISION		v230914		Product fiche and information – Hot water storage tanks																				
I Energy efficiency class		II Standing loss [W]				III Storage volume [l]					IV Storage volume [l]					V Standing loss [W]								
EU regulation		812/2013		814/2013		EU regulation					812/2013		814/2013			EU regulation					812/2013		814/2013	
Model	I	II	III	IV	V	Model	I	II	III	IV	V	Model	I	II	III	IV	V	Model	I	II	III	IV	V	
VISION EBT 60L	C	56	64	64,0	55,6	VISION 200	B	59	186	186,4	59,4	VISION EBT 500L	B	73	491	491,4	72,6							
VISION EBT 80L	C	60	75	75,0	59,9	VISION EBT 200L	B	53	193	193,3	52,6	VISION 500N ErP-B	B	71	476	476,4	70,6							
VISION 80Z	B	44	73	73,4	44,1	VISION 200NDUAL ErP-B	B	49	184	184,3	49,4	VISION 500NDUAL ErP-B	B	76	465	465,3	76,1							
VISION 80FTZ	B	45	75	75,3	45,3	VISION 200FMN ErP-B	B	48	186	186,4	47,5	VISION 500L HP	B	71	441	441,4	70,6							
VISION 100Z	B	47	91	91,3	47,3	VISION 200L HP	B	48	182	182,4	47,5	VISION 500L HP2	B	76	435	435,3	76,1							
VISION 100FTZ	B	48	89	89,3	47,7	VISION 200L HP2	B	49	180	180,3	49,4	VISION 750 ErP-A	-	-	-	738,4	62,8							
VISION 120Z	B	51	112	112,4	50,5	VISION EBT 300L	B	50	272	272,4	49,8	VISION 750DUAL ErP-A	-	-	-	721,4	66,5							
VISION 120FTZ	B	50	108	107,5	50,1	VISION 300N ErP-B	B	50	264	264,3	50,2	VISION 1000 ErP-B	-	-	-	936,3	134,7							
VISION EBT 120L	C	68	116	116,4	68,3	VISION 300NDUAL ErP-B	B	52	258	258,4	51,8	VISION 1000DUAL ErP-C	-	-	-	920,3	136,8							
VISION 150FN ErP-B	B	46	145	145,3	45,6	VISION 300L HP	B	50	249	249,3	50,2													
VISION 150FTZ	B	53	141	141,0	53,2	VISION 300L HP2	B	52	246	246,2	51,8													
VISION 150MZ	B	54	142	142,0	53,8																			
VISION 150MZDUAL	B	54	140	140,0	53,6																			
During product installation, use, service, and maintenance it is compulsory to comply strictly with all instructions in the user guide for installation and usage, as well as with product warranty card.																								
Once the product lifetime is terminated it must be dumped in accordance with the provision of legislation in force (regulations and directives) concerning its correct disassembly, disposal, and recycling, as well protection of mankind and the environment.																								