



Installation Guide

Accessories HRB, HFE Coupling




		HRB 3 065B2220 ---> 065B2230
		HRB 4 065B2240 ---> 065B2246


		HFE 3, HFE 4 065B5120 ---> 065B5250 065B6132 ---> 065B6250
		HRB 3, HRB 4 ¹⁾ 065B2177 ---> 065B2206 HRE 3, HRE 4 ¹⁾ 065B5019 ---> 065B5051 065B6019 ---> 065B6051

¹⁾ gen ---> 2008


1



2




HRB 3




HRB 4

3



HRB 3



HRB 4

4

