

Mounting systems for solar technology



ASSEMBLY INSTRUCTIONS
S-DOME 2.0 SYSTEM

GB

TABLE OF CONTENTS

TABLE OF CONTENTS	2
THE COMPANY	3
SAFETY REGULATIONS	4
MATERIALS REQUIRED	5
TOOLS REQUIRED	8
ASSEMBLY	9

PARTNER WITH A SYSTEM

With sophisticated, fully developed product ideas and obvious customer-orientation, K2 Systems is your friendly partner in the field of mounting systems for solar technology. International customers appreciate the tried and tested designs for use on roofs and in outdoor and individual solutions.

Mounting systems from K2 Systems impress with their attractive design and many well thought-out details. High grade materials and quality workmanship guarantee outstanding functionality and durability.

Our products consist of few yet perfectly matching components - this reduces the amount of material used, simplifies assembly while saving time and money.

As an energetic, experienced company, and in keeping with the times, we benefit from cooperation as partners in order to ensure the dynamic development of our company. The experiences from the personal dialogue with our customers forms the basis for permanent optimisation of our range of products.

The K2 Systems team looks forward to a successful cooperation with you.

TESTED QUALITY - MULTIPLE CERTIFICATIONS

K2 Systems stands for secure connection, highest quality and precision. Our customers and business partners have known that for a long time. Independent institutes have tested, confirmed and certified our capabilities and components.



Please refer to
<http://www.k2-systems.uk.com/downloads/certificates.html>
to download our quality and product certificates.

GENERAL SAFETY INSTRUCTIONS


Please note that our general mounting instructions must be followed at all times and can be viewed online at www.k2-systems.com/en/downloads/product-information.html.

The following guidelines apply:

- The equipment may only be installed and operated by qualified and adequately trained installers.
- Prior to installation, ensure that the product complies with on-site static loading requirements. For roof-mounted systems, the roof load-bearing capacity must always be checked.
- National and local building regulations and environmental requirements must be adhered to.
- Compliance with health and safety regulations, accident prevention guidelines and applicable standards is required:
 - Protective equipment such as safety helmet, boots and gloves must be worn.
 - Roofing works must be in accordance with roofing regulations utilising fall protection safeguards-when eaves height exceeds 3 m.
 - At least two people must be present for the duration of the installation work in order to provide rapid assistance in the event of an emergency.
- K2 mounting systems are continuously developed and improved and the installation process may thereby change at any time. Prior to installation consult our website at www.k2-systems.com/en/downloads/product-information.html for up-to-date instructions. We can send you the latest version on request.
- The assembly instructions of the module manufacturer must be adhered to.
- Equipotential bonding / grounding / earthing between individual parts is to be performed according to country specific standards, as well as national laws and regulations.
- At least one copy of the assembly instructions should be available on site throughout the duration of the installation.
- Failure to adhere to our general safety and assembly instructions and not using all system components, K2 is not liable for any resulting defects or damages. We do not accept liability for any damage resulting in the use of competitor's parts. Warranty is excluded in such cases.
- If all safety instructions are adhered to and the system is correctly installed, there is a product warranty entitlement of 12 years.
- We strongly recommend reviewing our terms of guarantee, which can be viewed at www.k2-systems.com/en/downloads/product-information.html. We will also send this information on request.
- Dismantling of the system is performed in reverse order to the assembly.
- K2 stainless steel components are available in different corrosion resistance classes. Each structure or component must be carefully checked for possible corrosion exposure.

REQUIRED MATERIALS

In order to assemble the K2 Systems S-Dome installation system, the following listed system components are essential. The piece quantities are calculated on the basis of the respective requirements. The listed item numbers facilitate the comparison of items.



Mounting Rail K2 SpeedRail 22; 880 mm

| 2002031

Material: aluminium EN AW-6063 T66




K2 Dome S1000 2.0

| 2001967

Width: 65 mm

Material: aluminium EN AW-6063 T66



K2 Building protection mat Dome Alu

| 2001695

470x180x18 mm

Material: PUR-bound rubber granules with aluminium triplex foil, laminated

Alternatively: K2 Building protection mat Dome

| 2001696

470x180x18 mm

Material: Unlaminated PUR-bonded rubber granulate

The respective use of a laminated or unlaminated building protection mat depends on the type of roof membrane and must be checked on site.




K2 Dome SD 2.0

| 2001968

Width: 65 mm

Material: aluminium EN AW-6063 T66



K2 Building protection mat Dome SD Alu

| 2001739

160x180x18 mm

Material: PUR-bonded rubber granules with aluminium triplex foil, laminated

Alternatively: K2 Building protection mat Dome SD

| 2001740

160x180x18 mm

Material: Unlaminated PUR-bonded rubber granulate

The respective use of a laminated or unlaminated building protection mat depends on the type of roof membrane and must be checked on site.



K2 Washer 8.4x30x1.5 mm

| 1000273

Material: stainless steel A2




K2 Allen bolt

| 1000085

M8x16 DIN EN ISO 4762

Material: stainless steel A2, WS 6 mm



K2 Windbreaker Dome S1000

| 1005843

For module length between 1601 and 1700 mm

Length: 1700 mm

Material: aluminium

Alternatively: K2 Windbreaker Dome S1000 1600 mm

| 2001119

For module length between 1550 and 1600 mm

Length: 1600 mm

Material: aluminium




K2 Bolts with serrated under head

| item number
system-specific

according to M8 DIN 912/EN ISO 4762

Material: stainless steel A2, WS 6 mm



M K2 Slot nut with clip

| 1001643

Material: stainless steel, PA



K2 Module End Clamp Standard Set

| item number
system-specific

The set consists of:

- 1 Module End Clamp Standard, Aluminium plate finished/ black anodized
 - 1 bolt with serrated under head M8, WS 6 mm, stainless steel A2
 - 1 M K2 Slot nut with clip (1001643), stainless steel and PA
 - 1 spring, stainless steel
-




K2 Module Middle Clamp XS Set

| item number
system-specific

The set consists of:

- 1 Module Middle Clamp XS, Aluminium plate finished/ black anodized
- 1 bolt with serrated under head M8, WS 6 mm, stainless steel A2
- 1 M K2 Slot nut with clip (1001643), stainless steel and PA
- 1 spring, stainless steel

OPTIONAL COMPONENTS FOR BALLASTING:



K2 Short Porter Set

| 2001946

Ballast support for slabs

The set consists of:

- 2 K2 Short Porter (2001934), aluminium EN AW-6063 T66
- 2 M K2 slot nuts with clip (1001643), stainless steel, PA
- 2 DIN 7991 hexagon socket countersunk head screws M8x20, stainless steel



K2 Dome Porter 1750 mm

| 2000081

Ballast support for slabs

Pair of L-Profiles to carry required ballast as concrete slabs or similar
Material: aluminium

Alternatively: K2 Dome Porter 2050 mm

| 2001140



K2 Dome Porter Screw Set

| 2000155

(optional to the K2 Dome Porter) one set per Porter

The set consists of:

- 2 M K2 slot nuts with clip (1001643), stainless steel, PA
- 2 bolts with serrated under head M8x20 (2001729), WS 6 mm, stainless steel A2

AT A GLANCE: OVERVIEW OF THE TOOLS

K2 Systems mounting systems are designed to ensure effortless assembly. The following recommended tools are not included in the scope of supply:



Torque wrench
WS 5 mm and 6 mm
(WS= wrench size)



Chalk line



Tape measure



Cordless screwdriver
With mount for WS 5 mm and 6 mm


IN GENERAL:

- From the onset, it is essential to clarify, whether a module manufacturer's approval is available for clamping on the short side of D-Dome S1000 system. You can obtain the approval list from your customer consultant or at www.k2-systems.com. If no module approval is available, or if the occurring loads exceeding 2750 Pa, the alternative S-Level 2.12 installation system must be used!
- K2 components made of stainless steel are available in different corrosion resistance classes. Each structure or component must be carefully checked for possible corrosion exposure.
- The General Installation Instructions must be adhered to.
These can be found at: <http://www.k2-systems.uk.com/downloads/product-information.html>
- This system can be used on all established flat roof constructions with a pressure resistant substrate and a roof pitch of up to 5°. When roof pitch exceeds 3°, the system must additionally be mechanically fastened. The inclination of the Dome 2.0 systems is 10°.
- Any structural-physical aspects must be observed. With any doubts consult an expert (i.e. structural engineer) with enquiries.
- Prior to placing down the SpeedRail as a base rail, a protection layer should be used between the roof covering and the rail to avoid any damages to the roof covering. Place the Speedrail onto the protection layer without penetrating the roof. The installer must ensure that the building protection mat is compatible with the roofing material on site. The protection layer is not part of the mounting system, but is strongly recommended.
- Ensure that the mounting rail segments and building protection mats are clean and dry (at most slightly moist from being wiped) before installation.
- The roof covering should be clean and level. If necessary any unevenness has to be levelled out or removed.
- A minimum distance of 500 mm from roof edges and 300 mm from all other obstructions (i.e. skylights, vents or similar) must be maintained.
- At least 1 row of three modules must be installed consecutively in order to use this system.
- The module distance according to the planning specifications of K2 Systems must be adhered to.
- The K2 S-Dome 2.0 System is suitable for modules with a frame height of 30 - 50 mm. This system is not suitable for thin-film modules.
- Modules with widths between 1550 - 1700 mm and a width between 950 - 1100 mm can be used.
- A thermal separation (min. 30 mm, max. 150 mm) must be installed at least every 13.50 m in the direction of the module row and in the direction of the base rail segments. It is essential that the system and its components do not block the draining of rain water.

INSTALLATION OF S-DOME 2.0 SYSTEM: STEP BY STEP

1
of 5

PRE-ASSEMBLING DOME SD 2.0 AND S-DOME 1000 2.0:




Lay the building protection mats with the aluminum-covered side (if used) facing down.

Lay the SpeedRail on top of the building protection mats and connect via snap tabs.

Insert the M K2 slot nuts into the rails and turn 90° clockwise to lock in place.

Position Dome S1000 2.0 and Dome SD 2.0 on the SpeedRail 880 mm according to the illustration and the spacing distances given in the assembly instructions and fix in place with Allen bolts and the MK 2 slot nut.


Tightening torque: 16 Nm



The spacing distance L is determined according to the following formula:

Spacing L =
row spacing – module width x 0.98 – 180 mm.

The row spacing was determined during the layout in K2 Base and can be seen on the assembly instructions.




At the first row of each array mount each Dome SD to a SpeedRail with a length of 520 mm.


The parallel spacing between the SpeedRails depends on the module width (950 - 1100 mm) and is determined by the end positions during installation.

INTERPRETATION

Pre-assemble all Dome components on the short rails accordingly and install on the roof according to the following scheme:




- Align two edges. East or west and north or south.
- Use alignment string or mark with a chalk line
- Roughly spread out pre-assembled rail segments with Dome components over the roof
- Align first row to the line



- Now assemble the modules on the first row with the components; move across the spread-out components from the opposite side
- Assemble all parts to the appropriate edge up to the stop position


POSITION AND FASTEN MODULE



Fix the module in place at the end of a row with module end clamp sets. Insert clamp sets in the S1000 and SD 2.0 notches and rotate 90°.


Fasten clamps to the module frame with an Allen bolt.

Tightening torque: 14 Nm.




Between every two modules, use two XS middle clamp sets. Insert clamp sets in the S1000 and SD 2.0 notches and rotate 90°. Place the clamps onto the module frame and fix them in place.

Tightening torque: 14 Nm




- Start laying the next row at the reference line
- Always assemble modules at the stop point
- Ensure that the clamps are securely fastened


INSTALL THE WINDBREAKER



- Use a ballast with the Dome S1000 2.0 where necessary. See page 14.
- Fix module cable in place



Align upper beading of the wind breaker with the ridge of the Dome S1000 2.0. (Surface with foil faces outwards.)



Align wind breaker at the module edge and fix in place via slotted holes with M8x16 Allen bolts and washers in screw channel.




Remove protective film.

! If two wind breakers overlap, align them so that a screw (including washer) can be bolted through the slotted hole!

! Ensure the wind breaker does not protrude beyond the end of the row!
Tightening torque: 16 Nm


BALLASTING THE SYSTEM

In some areas, the system may need to be outfitted with ballast.
If this needs to be done, please refer to the following ballast table.

non-binding ballast weight table					
Recommended ballast weight components	brick dimensions [cm]*	Maximum number of bricks in S1000 2.0 (2001967)	Maximum number of bricks in ballast components	Brick weights [kg]*	Ballast per S-Dome 2.0 elevation [kg]
 S1000 2.0	10x10x10	1		2.2	2.2
	20x10x8	1		3.5	3.5
	20x10x10	1		4.5	4.5
 K2 Short Porter	20x20x6		2	5.4	10.8
	20x20x8		2	7.2	14.4
	40x40x4		2	14.0	28.0
	40x40x5		2	19.0	38.0
	50x50x4		2	22.0	44.0
 K2 Porter	40x40x4		6	14.0	84.0
	40x40x5		6	19.0	114.0
	50x50x4		6	22.0	132.0


Warning: Pay attention to module inclination when using Short Porter and Porter!
For ballast weights exceeding 100 kg, please consult a K2 technician.

* recommended values




Ballasting without additional item(s):

For ballast of up to 5 kg, one or two individual weight bricks can be placed in the cavity of the S1000 2.0.




Ballasting with K2 Short Porter:

Affix each Short Porter (L-bracket) on the SpeedRail using an MK 2 slot nut and a countersunk screw.





The spacing between the Short Porters depends on the size of the ballast bricks chosen.
Tightening torque: 16 Nm




Use as much ballast as possible in front of the first row of each array per module and distribute the remaining ballast in the area of the back upstand. Position the building protection mats in accordance with the ballast centre of gravity.

Ballasting with K2 Porter:


Mount the Porters within a module block according to the drawing in an offset fashion, and distribute the ballast evenly.




Fix Porters (L-brackets) in place on the parallel SpeedRails with MK 2 slot nuts and countersunk screws.




The distance between the Porters depends on the size of the ballast bricks chosen; due to the length of the SpeedRail, bricks with a maximum width of 50 cm may be used.
Tightening torque: 16 Nm



Use as much ballast as possible in front of the first row of each array per module and distribute the remaining ballast in the area of the back upstand. When space is limited, use as much as possible in the area of the back upstand and the remaining part in the row spacing.



Position the building protection mats in accordance with the ballast centre of gravity.



THANK YOU FOR CHOOSING A K2 MOUNTING SYSTEM.

Systems from K2 Systems are quick and easy to install. We hope these instructions have helped. Please contact us if you have any questions or suggestions for improvements.

<http://www.k2-systems.uk.com/contact.html>

Our General Terms of Business apply. Please refer to <http://www.k2-systems.com/en/gsc.html>.

Mounting systems for solar technology



SERVICE HOTLINE
+49 (0)7159 42059-0
Info@k2-systems.de

Installation of S-Dome 2.0 | GB2 | 0116 | Subject to change.
Product illustrations are exemplary and may differ from the original.